



Subsection 02 (COOLING SYSTEM)

WATER PUMP




Section 01 V-810 ENGINE
Subsection 03 (LUBRICATION SYSTEM)



Section 01 V-810 ENGINE

Subsection 04 (MAGNETO SYSTEM)




vmmr2006-041-001_a

Section 01 V-810 ENGINE


Subsection 05 (CYLINDER AND HEAD)

NOTE: For cylinder head, cylinder and piston removal, it is not necessary to remove engine from vehicle.


FRONT CYLINDER HEAD (NO. 1)




REAR CYLINDER HEAD (NO. 2)



CYLINDERS AND PISTONS



Section 01 V-810 ENGINE
Subsection 06 (BOTTOM END)



Section 01 V-810 ENGINE
Subsection 06 (BOTTOM END)

